


AS_1000_01 Tower Assembly

ITEM NO.	PART NUMBER	QTY.
1	PP_1001_01 Tower Footer	1
2	PP_1002_01 Tower Header	1
3	PP_1003_01 Tower Shaft	1
4	SP_1005_01 Tower Pole	1
5	SP_1002_01 Location Bearing	2
6	SP_1006_01 Slip Ring	1
7	SP_1009_01 R18 O-Ring	1



SECTION A-A
SCALE 1 : 1